

Additional equipment needed:

- power drill with $\varnothing 8$ or 10 mm bit
- no. 8 mechanical or chemical anchors M8 or M10
- no. 8 washers M8 or M10

1. Make sure that the ground is level and solid enough (concrete, asphalt, stone or porphyry are all suitable materials).
2. Drill in the ground nr. 8 holes concentric with the pre-drilled holes in the baseplate.
3. Fix the baseplate with nr. 8 mechanical or chemical anchors and washers.

