

BLOOM LITTER BIN

INSTALLATION INSTRUCTIONS:

Lift the lid of the bin and make two holes of 8 mm diameter on the floor in correspondence of the two holes at the base of the bin.

Then fix the bin to the floor with M8 bolts or chemical anchors M8 (not supplied).

Close the cover after inserting the sack.

